stortech | Components and CCTV specialist

NETWORK CAMERA

Installation and Programming Manual

SNV-20XX0T/FS Series

Version 1 05/2023.

Network Camera

Installation and Programming Manual

Disclaimer

Stortech Electronics does its best to ensure the integrity and accuracy of the contents in this document and cannot guarantee this. The outcome of using this document shall be entirely the user's own responsibility. Stortech Electronics reserves the right to change the contents of this document without prior notice.

- Design and specifications are subject to change without prior notice.
- The default login is Admin, there is no password set when logging in for the first time. It is important that a password is then created.
- It is the responsibility of the user to ensure the security and management of the password.

Important Safety Instructions

1. Read, keep, and follow these instructions.
2. Only use the power supplies that are recommended in the manual, failure to do so could result in damaging the product.
3. When cleaning the product's surface use a soft, dry cloth or a damp cloth. Do not use detergent or products that contain alcohol, solvents or surfactants or oil constituents, they may damage the product. Especially the viewing bubble/window)
4. Do not use excessive force when installing the product, the camera may be damaged and fail to work. If the warranty seal is damaged, the warrantee will be void.
5. Install or uninstall the product as described in the manual, failure to do so may damage the product, affect the functions and performance that could invalidate the warrantee.
6. Install the product by referring to "Installation & connection" in the user manual.

Contents

Overview

- Product Features
- Recommended PC Specifications
- Packaging List

Installation

- Installation

Network Connection and Set-up

- Connecting the Camera directly to a Local Area Networking (LAN)
- Connecting directly to a DHCP server
- Router via the PoE/Cable Modem

Web-Viewer

- Connecting to the camera
- Password setting
- Log in.
- Plug-in support specification for each browser
- Installing Web Viewer Plugin
- Using a Plug-in free Web Browser
- Using the Live Screen
- Playing the recorder video

Setup Screen

- Setup
- Video & Audio Setup
- Network Setup
- Event Setup
- Analytics Setup
- System Setup

Addendum

- Specification
- Product Overview
- Trouble Shooting

Overview

Product Features

- Max. 2megapixel (1920 x 1080) resolution
- 2.1mm & 3.6mm lens options
- Max. 25fps/PAL all resolutions,4MP max20fips/PAL (H.265/H.264)
- H.265, H.264 Compression
- Day & Night (ICR) & Colour only options
- WDR, BLS, De-noise
- 12 x 850nm, 10m Illumination
- Privacy Zones
- Image Mirror
- PoE options
- Metal & ABS options
- ONVIF Profile S
- For more information, refer to www.onvif.org.

ONVIF
Driving network video through global standardization

Recommended PC Specifications

- CPU: Intel(R) Core (TM) i7 3.4 GHz or higher
- RAM: 8G or higher
- Supported OS: Windows 7, 8.1, 10,
- plug-in free web viewer
- Supported web browsers: IE(Best) Google Chrome, MS Edge, Mozilla Firefox (Windows 64bit only),
- plug-in web viewer

Packaging List

- Camera x 1
- Instruction manual x 1 (Via QR Code)
- Hex-key x 1
- M3 Torx-type screw x 3
- Mounting screw x 3
- T6 Torx-type key x 1

Installation

This camera is waterproof IP67, however the RJ45 socket on the Cat6 is not unless it is paired with the correct weatherproof plug.

Precaution

Before installing the camera ensure you read out the following instructions:

- The wall or ceiling that the camera is installed upon to withstand 5 x times the weight of the camera.
- Any excessive force used when installing the product may cause damage and/or malfunction.

Installation

1. If the camera is to be flush-mounted, create a hole in the mounting surface of the diameter no greater than 42mm for the base to fit into.
2. If the camera is to be surface mounted, you will need the Surface mount wedge.
3. Unscrew the top cover④, if tight apply pressure to polycarbonate dome to compress O-ring seal while unscrewing the top cover ③.
4. Note: The hexagon screw ②is found in the enclosed plastic bag to prevent being lost during installation.
5. Attach the mounting base ④to wall or ceiling, as required. Using the supplied screws ⑤. A firm mounting surface is essential for a stable installation.
6. Connect the appropriate cables to the camera.
   - Cameras with a suffix “P” are powered by PoE (IEEE 802.3af). Without a separate Power supply is required.
7. To adjust camera position, loosen the inner knurled ring ⑥, gently hold the ball camera ⑧ and turn until it is pointing in the correct direction.
8. To adjust the sharpness of the focus, loosening the focus-lock screw ⑦, before turning the lens. Then re-lock the focus-lock screw.
9. Lock the ball in place by rotating the inner knurled ring clockwise.
10. Replace the perspex cover and top cover.
11. Re-tighten the hex-head screw ② to lock the dome camera.





Item	Contents
Connector	RJ45
Ethernet	10/100Base-T
Cable	UTPCategory5e
Max Distance	100M
PoE Support	IEEE802.3af

Remote Setting

Connecting the Camera directly to a Local Area Networking (LAN)

This camera can be connected to using Stortech VMS software, a Network Video Recorder (NVR) or a Web-Browser. This manual will show how to connect and set up via a Web-Browser. The set up via Stortech's VMS software, or an NVR, please refer to the separate manuals.

While it is not always necessary, it is good practice to disable the PC's Wi-Fi.

1. The camera's default IP address is 192.168.1.10. Set your PC to an appropriate IP address such as 192.168.1.1. with a subnet Mask of 255.255.255.0.
2. Ensure that the camera is powered up, either via a PoE switch or separate power supply.
3. Ensure your PC is connected to the same switch and green flashing lights are on both switch ports.
4. Launch an Internet Browser on the local PC.
5. Enter the camera's IP address in the address bar of the browser.
6. Once the login page appears, click "login". It will ask if you wish to set the P/W now or "next time". It is best practice to set the P/W now.







A A choice of MJPEG (Default), VCL or QuickTime via plugins. You can view your image in 4:3, 16:9 or Full Screen.

B Live Viewing, to watch the life image

C AI Intelligence

D Remote Settings – Camera configuration

E Local Settings

F Logging out of Camera

G Viewing Window

Camera Config

OSD Configuration

1. Name	Choose the camera's name
2. Overlay information	Such as resolution
3. Channel Display	Enable/Disable
4. Time Display	Enable/Disable

Image Control

1. Default	Returns this page to factory default
2. Smart Night	Prioritise, White light, Infra-Red light, or Intelligent Light (Camera decides best option).
3. Image Mode	Options include Standard, Faceless or Numberplate exposures. Reduces over exposure due to bright light
4. Work Mode	Manual
5. Onset brightness threshold	(Check)Control the light on/off time. The numerical valueless than the light will be on earlier and off later
6. IR-Cut Reverse	Manually removes the IR-Cut filter during the day.
7. Brightness/ Contrast/ Saturation/Hue/Sharpness	Adjusts the settings of each over a percentage of 0 - 100
8. Defog	Autoengages frame integration technology to make foggy/rainy scenes clearer.
9. Flicker Control	Options of 50Hz or 60Hz, strobe light flickering compensation
10. The Flash strength	An exposure setting for indoor fluorescent lights strobe timings.



Remote Setting

Privacy Zones

The ability to set up to 4 separate zones to hide sensitive areas from view.



Network Configuration

1. IP Type	Static, DHCP, Auto Dynamic Host Configuration Protocol,
2. Auto IP	IPv4, IPv6
3. IP Address	Entering the Static IP Address
4. Subnet Mask	If you have a Static IP Address, you must set the Subnet Mask. Commonly set to 255.255.255.0 unless IT admin have allocated one
5. Gateway	This is the local IP address of the broadband router
6. Primary DNS	DNS (Domain Name Service) server address.
7. Alternative DNS	Secondary Address
8. MAC Address	The unique name given to every IP product, created in the factory.



Port Configuration

1. HTTP Port	HTTP port used to access the camera via the web browser. The default is 80(TCP), setting for Safari and Google Chrome browsers to 65535 is not allowed by security policy.
2. Command Port	Used in FTP to communicate the TCP port number to use for the data transfer channel.
3. Media Port	Passive Objects



Remote Setting

Third Party Trigger

Not applicable in European and UK Markets

RTSP Streaming port

1. RTSP	RTSP: Used to transfer videos in the RTSP mode; the default is 554.



P2P Configuration

Not applicable in European and UK Markets

Code Parameters

There are 10 video streams coming from the camera, the MainStream and 9 SubStream. The process of configuration is the same.

1. Stream Type	Video or Video & Audio
2. Video Codec	H.264 / H.265 Compression
3. Resolution	2560 x 1440, 2304 x 1296, 1920 x 1080, 1280 x 720
4. I frame interval	Between 1 – 200, the number of Partial frames (P-Frames) between each Full frame (I-Frame).
5. FPS	The number of frames per second (FPS) max25, (except 2560*1440 20FPS).
6. Rate Control	CBR (Constant Bit Rate) default / VBR (Variable Bit rate)
7. Quality	5 settings between Highest, High, Medium, Low, Lowest)



Audio Parameters

1. Audio Stream	Video or Video & Audio
2. Audio-in Codex	G711U/ G.711A Formats
3. Input volume	Adjusts the settings of each over a percentage of 0 - 100
4. Output volume	Adjusts the settings of each over a percentage of 0 - 100



Capture Config

1. Image Resolution	640 x 360
2. Image Quality	High, Middle, Low



Remote Setting

AlarmConfig

1. Alarm Out	1 Out Put
2. AlamOut Name	Selectable Name
3. AlamOut Delay	Custom/Keep 1 – 600



System Config

1. Date Format	DD-MM-YY, YY-MM-DD etc.
2. Time Format	12-Hour / 24-Hour Clock
3. Device date time	Synchronic with local PC date/time
4. NTP Timing	Network Time Protocol Open/Closed
5. Time zone	Select the time zones the cameras are in.
6. Sync Interval	How often the cameras sync with the NTP server
7. Server Address	The network address of the NTP Server



Daylight Saving

1. Enable DST	Open / Closed
2. Daylight Saving Time Mode	Week/ Month
3. Time Offset	Between -1& 2 Hours
4. Start Time	Date & Time clocks go forward
5. End Time	Date & Time clocks go backwards



Local Setting

UserManagement

There are 6 Admin (x 1) and 5 user accesses to the camera, only Admin has the ability tole to change any parameters.



Device Info

This is for information only, showing Firmware, software, Device Serial Number and other important pieces of information.



PTZ Setting

1. PTZ	Open / Closed
2. PTZ Address	Based on RS485 addressing
3. Bitrate	PTZ Bit rate i.e.,115200 (Pelco)
4. PTZ Step	1
5. PTZ Protocol	Pelco D



Local Settings

Auto Reboot

1. Maintenance Mode	Select the Reboot frequency
2. Week Plan	Select the day for the Reboot
3. Maintenance Time	Select the Reboot time
4. Next Maintenance Time	The time the next Reboot is planned



Firmware (F/W) Upgrade
When new F/W is released, it can be loaded into the camera from here. It will ask you to brows your PC to the folder holding the F/W update.

Restore Default

1. Simple Recovery	To factory setting (not delete user data)
2. Full Recovery	To factory settings (all data delete)
3. Reboot	Restart the camera



Local Setting

1. Local Disk	Choose the recording disk
2. Record Path	Video recording position
3. SnapshotPath	Image recording position
4. File Type	Recording format Interval: video recording time (1/5/15/30/60min)
5. Save	Saving the changes



Intelligent Detection

Human shape detection

1. Enable	Enable/ Disable
2. Sensitivity	High, Medium, Low
3. Type	Sound output, Light alarm, Trigger Alarm out

Motion

1. Enable	Enable/ Disable



Defence Area

The area of interest split into up to 4 zones. There are 6 shape options to maximise your coverage. Triangle, Rectangle, Pentagon, “L” shape, Heptagon, and “T” shape



Voice alarm / Audible alarm

1.	Audible alarm	Enable / Disable
2.	Humanoid/man-made sound type	Custom, Police signal, Dog barking, Alert area, Monitoring area, Welcome, Deep-water warning, Private sector, Hazardous area, Valuable – Test & Check (Not available for this camera, need to contact with external speakers)
3.	Delay Time	Select between 1 – 600s
4.	Schedule	1 hourly increments by day &time





Light Alarm

1. Lighting mode	Always Open / Twinkle (Flashing)
2. Delay record	(1-60 secs)

N.B. This function is only triggered by human movement and will only work during the daylight hours

(Not available in this camera, need to connect with different IR LED board)



Overlay settings.

This function gives the option of having a visual alert of a frame surounding the object of interest, on either the Main or Subcode streams or both.

1. MainStream	Options of a visual frame around a human of object.
2. Subcode Stream	Options of a visual frame around a human of object.



	SNV-20XX0T-FS
VIDEO	
Imaging Device	1/3" 4MP GC4653
Total Pixels	2,560(H) X 1,440(V) approx. 4M pixels
Effective Pixels	1,920(H) X 1,080(V) approx. 2.M pixels default
Min. Illumination	Colour : 0.01 Lux / B/W : 0 Lux (IR LED) TD/N option (Colour 0.01Lux)
IR LEDs	12 x 850nm, 10m Illumination
LENS	
Focal Length	2.1mm & 3.6mm Options
Angular Field of View	3.6mm: 76˚(H) ~ 41˚(W) / 2.1mm: 104˚(H) ~ 56˚(W)
Lens / Mount Type	Fixed iris / Board-in type
Image Settings	
Overlay Information	Name, Resolution, Bitrate, Channel Inf, Time, Position
Privacy Zones	Up to 4
Smart Night	Intelligent Mode, Infrared Light, White light
Image Mode	Standard, Faceless exposure, License plate mode
IR-Cut Sensitivity	High, Medium, Low
Delay Interval	10 ~ 600s
IR-Cut Reverse	On/Off
Image Mirror	Close, Flip Horizontal, Flip Vertical, Flip Centre
Image adjustment	Brightness, Contrast, Saturation, Chromaticity, Sharpness
Anti Flash Mode	50HZ, 60HZ, Close
Aperture Type	Auto, Manual
Exposure Time	Auto, 1/25, 1/30, 1/50, 1/60, 1/100, 1/120, 1/150, 1/180, 1/480, 1/960, 1/1,000, 1/2,000, 1/4,000, 1/8,000, 1/10,000
Gain	Auto, 6db, 12db, 18db, 24db, 30db, 36db, 42db
White Balance	Incandescent, Warm, Fluorescent, Natural, Manual, Auto, Locked
Denoise 3D	Auto, Weak, Normal, Strong
BLC	Open, Close
WDR	Auto, Weak, Normal, Strong
Alarm Settings	
Audible alarm	Sound types, Custom, Dog, Alert, Warning, Monitoring, Hazardous area, Welcome, Private sector, Valuables, Private parking spaces. Delay time, before next alarm, 5, 10, 20 30 s
Schedules	All Day, Manual (by day/hour), Night, Day
Alarm Output	1 x Name, Delay, Custom/keep, 1 ~ 600 s
Light Mode	Light mode: Always open, Twinkle, Delay 1 ~ 60 s (daytime only)
Defence area	Human &Motion, (High. Med, Low) Audible, Light, Selectable zones (shape/size). Overlay for Human, Area by Main & Sub streams
System Settings	
Date/Time	Format, 12/24hr, Sync to PC, Sync to Network Time, Daylight Saving
System Log	All, System, Configuration, Record, User Management, Alarm Event, Exception Event, Storage Management,
NETWORK	
IP Type	Manual, DHCP, Auto
Ethernet	RJ-45 (10/100 BASE-T)
Video Compression Format	Main & Sub streams: Video & Audio/ Video, H265+ (H.264/H.265), KFI 100 ~ 200, FPS (1 ~ 20), VBR/CBR.
Resolution	Main code stream: 2560 x 1440, 2304 x 1296, 1920 x 1080, 1280 x 720 Sub code stream: 800 x 448, 704 x 576, 640 x 360, 352 x 288
Port Configuration	HTTP (80), Command Port (6060), Data Port (6066) (Defaults)
RTSP	Port default 554, Mainstream: rtsp://192.168.1.10:554/live/0/MAIN Sub stream: rtsp://192.168.1.10:554/live/0/SUB
Max. Framerate	H.265 / H.264: Max. 25fps at all resolutions 2560*1440 (20fps)
Bitrate Control	H.265 / H.264: CBR or VBR
Streaming Capability	Multiple streaming (Up to 10 profiles)
Image latency	Ave. 200ms
Audio In	Selectable (Mic in / Line in)
Audio Compression	G.711U G.711AFormats
Audio Communication	Input & Output volume Adjust.
IP	IPv4, IPv6
Protocol	ONVIF, P2P, CGI, HTTP, TCP/IP, IPv4, RTSP, UDP, NTP, DHCP, DNS
Snapshot Config	Image Resolution: 640 x 360, Quality (High, Med, Low)
Streaming Method	Unicast / Multicast
User Access	1 x Admin, 5 x User
Interface	ONVIF profile S, Proprietor API
Viewing/Setup S/W	Stortech VMS
ENVIRONMENTAL	
Operating Temp /Hum	-20°C ~ +55°C /10-95% RH
Ingress Protection / Vandal Resistance	IP67 / IK10
ELECTRICAL	
Power	48V PoE (IEEE802.3af, Class3) or RJ45+12V DC
MECHANICAL	
Colour / Material	Silver Metal
Dimensions (WxH)	, Ø94.8 x 75.4mm (TD/N Metal)
Weight	358g

PROBLEM	SOLUTION
When a Windows 10 user accesses the webviewer through Chrome or Firefox, the sound volume of the microphone changes periodically.	• This is what happens when the microphone driver has been set to the Realtek driver. Install the High-Definition Audio device (Windows Default Driver) or a third-party driver as the microphone driver.
No video is displayed when accessing the plug-in free webviewer on Safari via HTTPS.	• On the authentication popup window prompted when initially accessing https, click "View Authentication Certificate" and select the "Always trust when connecting to the designated webviewer IP" checkbox. • If the webviewer continues failing to display a video after you select "Next" on the message window below, press the command key+Q to exit the Safari browser, access again and follow the procedures stated above.
I can't access the camera from a web browser.	• Check to make sure that the camera's Network settings are appropriate. • Check to make sure that all network cables have been connected properly. • If connected using DHCP, verify that the camera is able to acquire dynamic IP addresses without any problem. • If the camera is connected to a Broadband Router, verify that port forwarding is properly configured
Viewer got disconnected during monitoring.	• Connected Viewers become disconnected up on any change to camera or network configurations. • Check all network connections. • If the camera is connected over an PPPoE network, it is possible for the Viewer to disconnect under poor network conditions.
The camera connected to the network is not detected in the Stortech VMS software program.	• Turn off the fire wall settings on your PC and then search for the camera again. • Some cameras are powered via POE, ensure the POE camera is connected to a POE switch
No image appears.	• If the transmission method is set to multicast, check whether the router the camera is connected to supports multicast on the LAN. • Pls check if the IP camera address is the same as other devices on the LAN.

UK CA CE

www.stortech.co.uk | Components +44 (0)1279 451100 | CCTV +44 (0)1279 419913 | sales@stortech.co.uk
Unit 2, Spire Green Centre, Pinnacles West, Harlow, Essex CM19 5TQ | Company registration number: 2217300 | VAT Registration Number: 493 0525 45

Whilst every effort has been made to ensure the accuracy of the information provided, no liability can be undertaken for any errors or omissions. All dimensions stated in this document are approximate. Stortech Electronics Ltd reserves the right to alter the specifications and introduce changes without prior notice. © Stortech Electronics 2023

stortech Components and CCTV specialist